



# Video Splitter Module

Mode Code: HVS-1008-1

## Installation

This Video Splitter is used to route the CATV or antenna signal to multiple locations. The Video Amplifier Module (HVA-1001) may be required to boost the RF signal for longer cable distance.

1. Place the module horizontally.
2. Push the module so the hook and tabs fall into the rail slots of the enclosure.
3. Slide the module LEFT and the spring fastener will automatically lock the module at the desired position.



## Operation

The male F-connector which is compatible with RG-59 or RG6 is used for each video coaxial cable. A video source is connected to the "IN" port located in the centre of the splitter. "OUTPUT" ports can route the input signal to up to 8 locations. It is recommended any unused ports be capped with 75ohm terminators.

